

Trouble shooting

1. No system was found after the search process.

- Try to make a ping from the command line, if return ok

Check the SD card on the AIO controller.

deleted files or change for an empty one.

2. The Atlantium system was displayed but without data.

-Wait a few minutes, the digi system is copying all the data from the controller and can take a few minutes.

-Check the software version controller (AIO)

if its lower or than 3.3.0 (The System works through FTP)

Uncheck the checkbox in the system details screen.

System Details ×

Buscar dirección IP

192.168.16.140 Q Buscar sistema

☒ TCP/IP

Número de serie	ID del cliente	Nombre
	Heker Yamim Eilat	HOME RZ104

-For an AIO software version up to 3.3.0, check on the controller
General tab -> Connection settings

If you use a converter, try to work on a baud rate of 9600

-If it is an AIO controller, try to close the digi and log in again.

The first connection with the AIO controller is through FTP (historical reasons)

After that, the communication changes to TCP/IP automatically.

